

NSK

BEARING DOCTOR

HANDLING, MAINTENANCE AND TROUBLESHOOTING



STAY IN MOTION. STAY IN CONTROL.

CONTENT

1. INTRODUCTION	3
2. BEARING HANDLING AND MAINTENANCE	4
2.1 Precautions for Handling	4
2.2 Mounting	5
2.3 Check the Operation	5
3. BEARING PERFORMANCE FACTORS	7
3.1 Bearing Noise	7
3.2 Bearing Vibration	7
3.3 Bearing Temperature	7
3.4 Effects of Lubrication	7
3.5 Selection of Lubrication	8
3.6 Replenishment and Replacement of Lubricant	9
4. BEARING INSPECTION	13
5. RUNNING TRACES AND APPLIED LOADS	14
6. BEARING DAMAGE AND COUNTERMEASURES	17
6.1 Flaking (or Spalling)	18
6.2 Scoring	20
6.3 Peeling	22
6.4 Fracture	23
6.5 Smearing	24
6.6 Cracks	26
6.7 Cage Damage	28
6.8 Denting	30
6.9 Pitting	31
6.10 Wear	32
6.11 Fretting	33
6.12 False Brinelling	34
6.13 Creep	35
6.14 Seizure	36
6.15 Electrical Erosion	38
6.16 Rust and Corrosion	40
6.17 Mounting Flaws	41
6.18 Discoloration	42
APPENDIX: BEARING DIAGNOSTIC CHART	43

1. INTRODUCTION

NSK

When a rolling bearing is damaged during machine operation, the entire machine or equipment may seize or malfunction. Since bearings that fail prematurely or unexpectedly cause unplanned downtime, it is important to be able to identify potential failures in order to avoid future risk.

Generally, bearing inspection or housing inspection can identify the cause of the problem. Often the cause is attributable to poor lubrication, improper handling, selecting the wrong bearing, or not enough study of the shaft and housing. Usually the cause can be determined by considering operation of the bearing before the failure, investigating the lubrication conditions and the mounting condition, and carefully observing the damaged bearing itself.

Sometimes bearings are damaged and fail both quickly and unexpectedly. Such premature failure is different from fatigue failure which is due to flaking. Bearing life can be separated and categorized into two types: premature failure and normal rolling contact fatigue.



2. BEARING HANDLING & MAINTENANCE

PRECAUTIONS FOR HANDLING

Since rolling bearings are high precision machine parts, they must be handled carefully. Even if high quality bearings are used, their expected life and performance cannot be attained if they are used improperly. The main precautions to be observed are as follows:


(1) Keep the bearings and surroundings clean: Dust and dirt, even if invisible to the naked eye, have harmful effects on bearings. It is necessary to prevent the entry of dust and dirt by keeping the bearings and their environment as clean as possible.



Keep Bearings
and Surroundings
Clean!



Handle
With Care!



Use
Proper Tools!



Protect Bearings
From Corrosion!

(2) Handle with care: Heavy shocks during handling may scratch or cause other damage to the bearing possibly resulting in premature bearing failure. Strong impacts may cause brinelling, breaking or cracking.

(3) Use proper tools:

Always use the proper tool when handling bearings and avoid general purpose tools.

(4) Protect bearings from corrosion:

Since perspiration on the hands and various other contaminants may cause corrosion, keep your hands clean when handling bearings. Wear gloves if possible.

MOUNTING

It is advisable to study the bearing mounting thoroughly since the quality of the bearing mounting influences the bearing's running accuracy, life and performance. It is recommended that the mounting method includes the following steps:

- › Clean the bearing and surrounding parts.
- › Check the dimensions and finish conditions of related parts.
- › Follow mounting procedure.
- › Check if the bearing is mounted correctly.
- › Supply with correct kind and quantity of lubricant.

Since most bearings rotate with the shaft, the bearing mounting method is generally an interference (tight) fit for the inner ring and shaft while giving a clearance (loose) fit for the outer ring and housing.

CHECK THE OPERATION

After mounting the bearing, it is important to carry out an operating test to confirm that the bearing is mounted properly. **Table 1** indicates operating test methods. If irregularities are detected, immediately suspend the test and consult **Table 2** which lists appropriate countermeasures to specific bearing problems.

MAINTENANCE

It is necessary to periodically inspect and maintain the bearing and its operating conditions in order to maximize the bearing life. In general, the following method is adopted.

INSPECTION UNDER OPERATING CONDITIONS

To determine the bearing replacement periods and replenishment intervals for lubricant, investigate the lubricant properties and consider factors such as operating temperature, vibration, and bearing noise. (Refer to Performance Factors section for more details.)

INSPECTION OF THE BEARING

Be sure to investigate the bearing thoroughly during times of periodic machine inspection and part replacement. If possible, check the raceway condition. Determine if damage exists. Confirm if the bearing can be reused or should be replaced. (Refer to Bearing Inspection section for more details.)



2. BEARING HANDLING & MAINTENANCE (CONT)

Table 1 Methods to check operation

MACHINE SIZE	OPERATING PROCEDURE	BEARING CONDITION CHECKS
Small machine	Manual operation. Turn the bearing by hand. If no problems are detected, then proceed to operate the machine.	<ul style="list-style-type: none"> › Stick-slip (Debris, cracks, dents) › Uneven rotating torque (Faulty mounting) › Excessive torque (Error in mounting or insufficient radial internal clearance)
	Power operation. Initially start at a low speed and without a load. Gradually increase speed and load to reach rating.	Check for irregular noise. Check for bearing temperature rise, lubricant leakage, and/or discoloration.
Large machine	Idle operation. Turn ON power and allow machine to rotate slowly. Turn OFF the power and allow the bearing to coast to a stop. If no irregularities are detected by the test, then proceed to the loaded rotation testing.	Vibration, noise, etc.
	Power operation. Follow the same power operation testing as used for small machine testing.	Follow the same checkpoints as the small machine test.

Table 2 Causes and countermeasures for operating irregularities

IRREGULARITIES	POSSIBLE CAUSES	COUNTERMEASURES
Noise	Loud Metallic Sound	Abnormal load
		Improve the fit, internal clearance, preload, position of housing shoulder, etc.
		Incorrect mounting
		Improve the machining accuracy and alignment of shaft and housing, accuracy of mounting method.
		Insufficient or improper lubricant
		Replenish the lubricant or select another lubricant.
		Contact of rotating parts
		Modify the labyrinth seal, etc.
Abnormal Temperature Rise	Loud Regular Sound	Flaws, corrosion, or scratches on raceways
		Replace or clean the bearing, improve the seals, and use clean lubricant.
		Brinelling
		Replace the bearing and use care when handling bearings.
		Flaking on raceway
		Replace the bearing.
Vibration (Axial runout)	Irregular Sound	Excessive clearance
		Improve the fit, clearance and preload.
		Penetration of foreign particles
		Replace or clean the bearing, improve the seals, and use clean lubricant.
		Flaws or flaking on balls
		Replace the bearing.
		Excessive amount of lubricant
		Reduce amount of lubricant, select stiffer grease.
Leakage or Discoloration of Lubricant	Insufficient or improper lubricant	Replenish lubricant or select a better one.
Leakage or Discoloration of Lubricant	Abnormal load	Improve the fit, internal clearance, preload, position of housing shoulder.
Leakage or Discoloration of Lubricant	Incorrect mounting	Improve the machining accuracy and alignment of shaft and housing, accuracy of mounting, or mounting method.
Leakage or Discoloration of Lubricant	Creep on fitted surface, excessive seal friction	Correct the seals, replace the bearing, correct the fitting or mounting.

3. BEARING PERFORMANCE FACTORS



Key bearing performance factors during operation are bearing noise, vibration, temperature, and lubricant state. Please refer to Table 2 if any operation irregularities are detected.

3.1 BEARING NOISE

During operation, sound detection instruments (stethoscope, NSK Bearing Monitor, etc.) can be used to investigate the volume and characteristics of the bearing rotation noise. It is possible to distinguish bearing damage such as small flaking by means of its unusual yet characteristic noise.

3.2 BEARING VIBRATION

Bearing irregularities can be analyzed by measuring the vibrations of an operating machine. A frequency spectrum analyzer is used to measure the magnitude of vibration and the distribution of the frequencies. Test results enable the determination of the likely cause of the bearing irregularity. The measured data varies depending on the operating conditions of the bearing and the location of the vibration pick-up. Therefore, the method requires the determination of evaluation standards for each measured machine. It is useful to be able to detect irregularities from the bearing vibration pattern during operation.

3.3 BEARING TEMPERATURE

Generally, the bearing temperature can be estimated from the temperature of the housing outside surface, but a preferable way is to obtain direct measurements from the bearing outer ring by a probe going through an oil hole. Usually, the bearing temperature gradually increases after the start of operation until reaching a steady state condition about 1 or 2 hours later. The bearing steady state temperature depends on load, rotational speed and heat transfer properties of the machine. Insufficient lubrication or improper mounting might cause the bearing temperature to rise rapidly. In such a case, suspend the machine operation and adopt an appropriate countermeasure.

3.4 EFFECTS OF LUBRICATION

The two main purposes of lubrication are to minimize friction and reduce wear inside bearings that might otherwise fail prematurely. Lubrication provides the following advantages:

- › **Reduction of Friction and Wear**

Direct metallic contact between the bearing rings, rolling elements and cage, which are the basic components of a bearing, is prevented by an oil film which reduces the friction and wear in the contact areas.

- › **Extension of Fatigue Life**

The rolling fatigue life of bearings depends greatly upon the viscosity and film thickness between the rolling contact surfaces. A heavy film thickness prolongs the fatigue life, but it is shortened if the viscosity of the oil is too low so that the film thickness is insufficient.

- › **Dissipation of Frictional Heat and Cooling**

Circulating lubrication may be used to carry away either frictional heat or heat transferred from the outside to prevent the bearing from overheating and the oil from deteriorating.

- › **Sealing and Rust Prevention**

Adequate lubrication also helps to prevent foreign material from entering the bearings and guards against corrosion or rusting.

3. BEARING PERFORMANCE FACTORS (CONT)

Table 3 Comparison between grease and oil lubrication


ITEM	GREASE LUBRICATION	OIL LUBRICATION
Housing structure and seal method	Simple	May be complex. Careful maintenance required.
Speed	Limiting speed is 65% to 80% of that with oil lubrication	High limiting speed
Cooling effect	Poor	Heat transfer is possible using forced oil circulation
Fluidity	Poor	Good
Lubricant replacement	Sometimes difficult	Easy
Removal of foreign material	Removal of particles from grease is impossible	Easy
External contamination due to leakage	Surroundings seldom contaminated by leakage	Often leaks if proper countermeasures are not taken. Not suitable if external contamination must be avoided.

Table 4 Required viscosity by bearing type

BEARING TYPE	VISCOSITY AT OPENING TEMPERATURE
Ball bearings, Cylindrical roller bearings	13 mm ² /s or more
Tapered roller bearings, Spherical roller bearings	20 mm ² /s or more
Spherical thrust roller bearings	32 mm ² /s or more

Notes: 1 mm²/s = 1 cSt (Centi-Stokes)

Fig. 1 Relation between oil viscosity and temperature



3.5 SELECTION OF LUBRICATION

Bearing lubrication methods are divided into two main categories: grease lubrication and oil lubrication. A lubrication method is adopted that matches the application conditions and application purpose in order to attain best performance from the bearing. **Table 3** shows a comparison between grease and oil lubrication.

› Grease lubrication

Grease is a lubricant that is made from base oil, thickener, and additives. When selecting a grease, it is necessary to select a grease that is suitable to the bearing application conditions. There are large differences in performance even between different brands of the same type of grease. Therefore special attention must be given to grease selection. **Table 5** gives examples of applications and grease consistency.

› Oil lubrication

There are several different oil lubrication methods: Oil bath, Drip feed, Splash, Circulating, Jet, Oil mist, and Oil air. Oil lubrication methods are more suitable for higher speed and higher temperature applications than are grease lubrication methods. Oil lubrication is especially effective in the case where it is necessary to dissipate heat to the exterior. Be sure to select a lubricating oil that has suitable viscosity at the bearing operating temperature. Generally, an oil with a low viscosity is used for high speed application while an oil with high viscosity is used for applications with heavy loads. For normal application conditions, **Table 4** lists the suitable viscosity range for the operating temperature.

For reference when making a selection, **Fig. 1** shows the relationship between temperature and viscosity for the lubricating oil. **Table 6** gives examples of how to select the lubrication oil for different bearing application conditions.

3.6 REPLENISHMENT AND REPLACEMENT OF LUBRICANT

Replenishing Interval

Even if high-quality grease is used, there is deterioration of its properties with time; therefore, periodic replenishment is required. **Figs. 2 (1) and (2)** show the replenishment time intervals for various bearing types running at different speeds. These apply for the condition of high-quality lithium soap-mineral oil grease, bearing temperature of 70° C, and normal load ($P/C=0.1$).

Temperature

If the bearing temperature exceeds 70° C, the replenishment time interval must be reduced by half for every 15° C temperature rise of the bearings.

Grease

In case of ball bearings especially, the replenishing time interval can be extended depending on grease type being used. (For example, high-quality lithium soap-synthetic oil grease may extend replenishing time interval by about two times that shown in **Fig. 2 (1)**. If the temperature of the bearings is less than 70° C, the usage of lithium soap-mineral oil grease or lithium soap-synthetic oil grease is appropriate.) It is advisable to consult NSK.

Load

The replenishing time interval depends on the magnitude of the bearing load. Please refer to **Fig. 2 (3)**, and multiply

the replenishing time interval by the load factor. If P/C exceeds 0.16, it is advisable to consult NSK.

Lubrication oil replacement interval

The oil replacement intervals depend on the operating conditions and the oil quantity. In general, for an operating temperature under 50° C, and in clean environments, the replacement interval is 1 year. If the oil temperature is above 100° C, then the oil should be changed at least once every three months.

Table 5 Examples of applications and grease consistency

CONSISTENCY NUMBER	CONSISTENCY (1/10 MM)	APPLICATION	
#0	355 to 385	Central grease supply	Where fretting occurs easily
#1	310 to 340	Central grease supply, Low temperature	Where fretting occurs easily
#2	265 to 295	General grease	Sealed ball bearings
#3	220 to 250	General grease, High temperature	Sealed ball bearings
#4	175 to 205	High temperature	Where grease is used as a seal

Table 6 Selection of lubricating oils for different bearing applications

OPERATING TEMPERATURE	SPEED	LIGHT OR NORMAL LOAD	HEAVY OR SHOCK LOAD
-30 to 0°C	Below limiting speed	ISO VG 15, 22, 32 (Refrigerator oil)	—
0 to 50°C	Below 50% of limiting speed	ISO VG 32, 46, 68 (Bearing oil, Turbine oil)	ISO VG 46, 68, 100 (Bearing oil, Turbine oil)
	Between 50% and 100% of limiting speed	ISO VG 15, 22, 32 (Bearing oil, Turbine oil)	ISO VG 22, 32, 46 (Bearing oil, Turbine oil)
	Above limiting speed	ISO VG 10, 15, 22 (Bearing oil)	—
50 to 80°C	Below 50% of limiting speed	ISO VG 100, 150, 220 (Bearing oil)	ISO VG 150, 220, 320 (Bearing oil)
	Between 50% and 100% of limiting speed	ISO VG 46, 68, 100 (Bearing oil, Turbine oil)	ISO VG 68, 100, 150 (Bearing oil, Turbine oil)
	Above limiting speed	ISO VG 32, 46, 68 (Bearing oil, Turbine oil)	—
80 to 110°C	Below 50% of limiting speed	ISO VG 320, 460 (Bearing oil)	ISO VG 460, 680 (Bearing oil, Gear oil)
	Between 50% and 100% of limiting speed	ISO VG 150, 220 (Bearing oil)	ISO VG 220, 320 (Bearing oil)
	Above limiting speed	ISO VG 68, 100 (Bearing oil, Turbine oil)	—

Notes: 1. As for the limiting speed, use the value listed under oil lubrication in the Bearing Dimension Tables of "NSK Rolling Bearings" (No. E1103).


2. Refer to refrigerator oil (JIS K 2211), Bearing oil (JIS K 2239), Turbine oil (JIS K 2213), Gear oil (JIS K 2219).

3. Temperature ranges are shown in the left column in the table above. For operating temperatures that are on the high temperature side, a high viscosity lubrication oil is recommended.


3. BEARING PERFORMANCE FACTORS (CONT)

Fig. 2 Grease replenishment intervals

(1) Radial ball bearing and cylindrical roller bearing



(2) Tapered roller bearing and spherical roller bearing



(3) Load factor

P/C	≤ 0.06	0.1	0.13	0.16
Load factor	1.5	1	0.65	0.45

Notes:

P : Equivalent load
 C : Basic load rating





4. BEARING INSPECTION



When inspecting a bearing during periodic equipment inspections, operating inspections, or replacement of adjacent parts, determine the condition of the bearing and if its continued service is advisable.

A record should be kept of the inspection and external appearance of dismounted bearings. After taking a grease sample and measuring the quantity of residual grease, the bearing should be cleaned. Also, determine whether abnormalities and damage exist in the cage, fitting surfaces, rolling element surfaces and raceway surfaces. Refer to Running Traces and Applied Loads (Section 5) regarding the observation of running traces on the raceway surface.

When evaluating whether a bearing can be re-used or not, the following points need to be considered: degree of bearing damage, machine performance, critical nature of the application, operating conditions, inspection interval. If the inspection reveals bearing damage or abnormalities, then try to confirm the cause and determine a countermeasure by referring to Bearing Damage and Countermeasures (Section 6) and then carry out the countermeasure.

If your inspection discovers any of the following kinds of damage, which would prevent the bearing from being reused, then the bearing must be replaced with a new bearing.

- (1) Cracks or chipping in the cage, rolling elements, or raceway ring.
- (2) Flaking in the rolling elements or raceway ring.
- (3) Notable scoring on the rolling elements, rib face (collar), or raceway surface.
- (4) Notable wear on the cage or loose rivets.
- (5) Flaws or rust on the rolling elements or raceway surface.
- (6) Notable dents on the rolling elements or raceway surface.
- (7) Notable creep of the outer ring outside surface or inner ring bore.
- (8) Discoloration due to heating.
- (9) Serious damage on shield or seal of grease packed bearings.

5. RUNNING TRACES AND APPLIED LOADS

As the bearing rotates, the raceways of the inner ring and outer ring make contact with the rolling elements. This results in a wear path on both the rolling elements and raceways. Running traces are useful, since they indicate the loading conditions, and should be carefully observed when the bearing is disassembled.

If the running traces are clearly defined, it is possible to determine whether the bearing is carrying a radial load, axial load or moment load. Also, the roundness condition of the bearing can be determined. Check whether unexpected bearing loads or large mounting errors occurred. Also, determine the probable cause of the bearing damage.

Fig. 3 shows the running traces generated in deep groove bearings under various load conditions.

Fig. 3 (a) shows the most common running trace generated when the inner ring rotates under a radial load only. **Figs. 3 (e) through (h)** show several different running traces that result in a shortened life due to their adverse effect on the bearings.

Similarly, **Fig. 4** shows different roller bearing running traces:

Fig. 4 (a) shows the outer ring running trace when a radial load is properly applied to a cylindrical roller bearing which has a load on a rotating inner ring.

Fig. 4 (b) shows the running trace in the case of shaft bending or relative inclination between the inner and outer rings. This misalignment leads to the generation of slightly shaded (dull) bands in the width direction. Traces are diagonal at the beginning and end of the loading zone. For double-row tapered roller bearings where a single load is applied to the rotating inner ring, **Fig. 4 (c)** shows the running trace on the outer ring under radial load while **Fig. 4 (d)** shows the running trace on the outer ring under axial load. When misalignment exists between the inner and the outer rings, then the application of a radial load causes running traces to appear on the outer ring as shown in **Fig. 4 (e)**.

Fig. 3 Typical running traces of deep groove ball bearings





Fig. 4 Typical running traces on roller bearings





6. BEARING DAMAGE AND COUNTERMEASURES



In general, if rolling bearings are used correctly, they will survive to their predicted fatigue life. Bearings, however, often fail prematurely due to avoidable mistakes. In contrast to fatigue life, this premature failure is caused by improper mounting, mishandling, poor lubrication, contamination or abnormal heat generation.

One cause of premature failure is rib scoring which is due to insufficient lubrication, use of improper lubricant, faulty lubrication system, entry of foreign matter, bearing mounting error, excessive deflection of the shaft or some combination of these.

If all conditions are known for the times both before and after the failure, including the application, the operating conditions, and environment, then a countermeasure can be determined by studying the

nature of the failure and its probable causes. A successful countermeasure will reduce similar failures or prevent them from happening again.

Sections 6.1 through 6.18 give examples of bearing damage and countermeasures. Please consult these sections when trying to determine the cause of bearing damage. The bearing diagnostic chart in the Appendix (page 43) is available as a quick reference guide.

6.1 FLAKING (OR SPALLING)

DAMAGE CONDITION

Flaking (sometimes referred to as spalling) occurs when small pieces of bearing material are split off from the smooth surface of the raceway or rolling elements due to rolling fatigue, thereby creating regions having a rough and coarse texture.

POSSIBLE CAUSE

- › Excessive load
- › Poor mounting (misalignment)
- › Moment load
- › Entry of foreign debris, water penetration
- › Poor lubrication, Improper lubricant
- › Unsuitable bearing clearance
- › Improper precision for shaft or housing, unevenness in housing rigidity, large shaft bending
- › Progression from rust, corrosion pits, smearing, dents (Brinelling)

COUNTERMEASURE

- › Reconfirm the bearing application & check the load conditions
- › Improve the mounting method
- › Improve the sealing mechanism, prevent rusting during non-running
- › Use a lubricant with a proper viscosity, improve the lubrication method
- › Check the precision of shaft and housing
- › Check the bearing internal clearance



Part:
Inner ring of an angular contact ball bearing

Observation:
Flaking occurs diagonally along raceway

Cause:
Poor alignment between shaft and housing during mounting



Part:
Inner ring of deep groove ball bearing

Observation:
Flaking of raceway at ball pitch

Cause:
Dents due to shock load during mounting



Part:
Inner ring of an angular contact ball bearing

Observation:
Flaking of raceway at ball pitch

Cause:
Dents due to shock load while stationary

6.1.1

6.1.2

6.1.3



Part:
Outer ring of Photo 6.1.3

Observation:
Flaking of raceway surface at ball pitch

Cause:
Dents due to shock load while stationary

6.1.4



Part:
Balls of Photo 6.1.3

Observation:
Flaking of ball surface

Cause:
Dents due to shock load while stationary

6.1.5



Part:
Inner ring of a spherical roller bearing

Observation:
Flaking of only one raceway over its entire circumference

Cause:
Excessive axial load

6.1.6



Part:
Outer ring of Photo 6.1.6

Observation:
Flaking of only one raceway over its entire circumference

Cause:
Excessive axial load

6.1.7



Part:
Inner ring of a spherical roller bearing

Observation:
Flaking of only one row of raceway

Cause:
Poor lubrication

6.1.8



Part:
Rollers of a cylindrical roller bearing

Observation:
Premature flaking occurs axially on the rolling surfaces

Cause:
Scratches caused during improper mounting

6.1.9

6.2 SCORING

DAMAGE CONDITION

Scoring is surface damage due to accumulated small seizures caused by sliding under improper lubrication or under severe operating conditions. Linear damage appears circumferentially on the raceway surface and rolling surface. Cycloidal shaped damage on the roller end. Scoring on rib surface contacting roller end.

POSSIBLE CAUSE

- › Excessive load, excessive preload
- › Poor lubrication
- › Particles are caught between surfaces with relative motion
- › Inclination of inner and outer rings
- › Shaft bending
- › Poor precision of the shaft and housing

COUNTERMEASURE

- › Check the size of the load
- › Adjust the preload
- › Improve the lubricant and the lubrication method
- › Check the precision of the shaft and housing

**Part:**

Inner ring of a spherical roller bearing

Observation:

Scoring on large rib face of inner ring

Cause:

Roller slipping due to sudden acceleration and deceleration

**Part:**

Convex rollers of Photo 6.2.1

Observation:

Scoring on roller end face

Cause:

Roller slipping due to sudden acceleration and deceleration

**Part:**

Inner ring of a tapered roller thrust bearing

Observation:

Scoring on the face of inner ring rib

Cause:

Worn particles become mixed with lubricant, and breakdown of oil film occurs due to excessive load

6.2.1

6.2.2

6.2.3



Part:
Rollers of a double-row cylindrical roller bearing

Observation:
Scoring on the roller end face

Cause:
Poor lubrication and excessive axial load

6.2.4



Part:
Inner ring of a spherical thrust roller bearing

Observation:
Scoring on the rib face of inner ring

Cause:
Debris, which is caught in surface, and excessive axial loading

6.2.5



Part:
Convex rollers of Photo 6.2.5

Observation:
Scoring on the roller end face

Cause:
Debris, which is caught in surface, and excessive axial loading

6.2.6



Part:
Cage of a deep groove ball bearing

Observation:
Scoring on the pressed-steel cage pockets

Cause:
Entry of debris

6.2.7

6.3 PEELING

DAMAGE CONDITION

Dull or cloudy spots appear on surface along with light wear. From such dull spots, tiny cracks are generated inward to a depth of 5 to 10 µm. Small particles fall off and minor flaking occurs widely.

POSSIBLE CAUSE

- › Unsuitable lubricant
- › Entry of debris into lubricant
- › Rough surface due to poor lubrication
- › Surface roughness of mating rolling part

COUNTERMEASURE

- › Select a proper lubricant
- › Improve the sealing mechanism
- › Improve the surface finish of the rolling mating parts



Part:
Inner ring of a spherical roller bearing

Observation:
Round shaped peeling pattern occurs on the center of the raceway surface

Cause:
Poor lubrication



Part:
Convex rollers of Photo 6.3.1

Observation:
Round shaped peeling pattern occurs on the center of the rolling surfaces

Cause:
Poor lubrication



Part:
Outer ring of a spherical roller bearing

Observation:
Peeling occurs near the shoulder of the raceway over the entire circumference

Cause:
Poor lubrication

6.3.1

6.3.2

6.3.3

DAMAGE CONDITION

Fracture refers to small pieces which were broken off due to excessive load or shock load acting locally on a part of the roller corner or rib of a raceway ring.

POSSIBLE CAUSE

- › Impact during mounting
- › Excessive load
- › Poor handling such as dropping

COUNTERMEASURE

- › Improve the mounting method (Shrink fit, use of proper tools)
- › Reconsider the loading conditions
- › Provide enough back-up and support for the bearing rib



Part:
Inner ring of a double-row cylindrical roller bearing

Observation:
Chipping occurs at the center rib

Cause:
Excessive load during mounting



Part:
Inner ring of a tapered roller bearing

Observation:
Fracture occurs at the cone back face rib surface

Cause:
Large shock during mounting



Part:
Inner ring of a spherical thrust roller bearing

Observation:
Fracture occurs at the large rib

Cause:
Repeated load

6.4.1

6.4.2

6.4.3

6.5 SMEARING

DAMAGE CONDITION

Smearing is surface damage which occurs from a collection of small seizures between bearing components caused by oil film rupture and/or sliding. Surface roughening occurs along with melting.

POSSIBLE CAUSE

- › High speed and light load
- › Sudden acceleration/deceleration
- › Improper lubricant
- › Entry of water

COUNTERMEASURE

- › Improve the preload
- › Improve the bearing clearance
- › Use a lubricant with good oil film formation ability
- › Improve the lubrication method
- › Improve the sealing mechanism



Part:
Inner ring of a cylindrical roller bearing

Observation:
Smearing occurs circumferentially on raceway surface

Cause:
Roller slipping due to excessive grease filling



Part:
Outer ring of Photo 6.5.1

Observation:
Smearing occurs circumferentially on raceway surface

Cause:
Roller slipping due to excessive grease filling



Part:
Inner ring of a spherical roller bearing

Observation:
Smearing occurs circumferentially on raceway surface

Cause:
Poor lubrication

6.5.1

6.5.2

6.5.3



Part:
Outer ring of Photo 6.5.3

Observation:
Smearing occurs circumferentially on raceway surface

Cause:
Poor lubrication



Part:
Inner ring of a spherical roller bearing

Observation:
Partial smearing occurs circumferentially on raceway surface

Cause:
Poor lubrication



Part:
Outer ring of Photo 6.5.5

Observation:
Partial smearing occurs circumferentially on raceway surface

Cause:
Poor lubrication



Part:
Convex rollers of Photo 6.5.5


Observation:
Smearing occurs at the center of the rolling surface

Cause:
Poor lubrication

6.5.4

6.5.5

6.5.6



6.5.7

6.6 CRACKS

DAMAGE CONDITION

Cracks in the raceway ring and rolling elements. Continued use under this condition leads to larger cracks or fractures.

POSSIBLE CAUSE

- › Excessive interference
- › Excessive load, shock load
- › Progression of flaking
- › Heat generation and fretting caused by contact between mounting parts and raceway ring
- › Heat generation due to creep
- › Poor taper angle of tapered shaft
- › Poor cylindricality of shaft
- › Interference with bearing chamfer due to a large shaft

COUNTERMEASURE

- › Correct the interference
- › Check the load conditions
- › Improve the mounting method
- › Use an appropriate shaft shape

**Part:**

Outer ring of a double-row cylindrical roller bearing

Observation:

Thermal cracks occur on the outer ring side face

Cause:

Abnormal heat generation due to contact sliding between mating part and face of outer ring

**Part:**

Roller of a tapered roller thrust bearing

Observation:

Thermal cracks occur at large end face of roller

Cause:

Heat generation due to sliding with the inner ring rib under poor lubrication

**Part:**

Outer ring of a double-row cylindrical roller bearing

Observation:

Cracks propagated outward in the axial and circumferential directions from the flaking origin on the raceway surface

Cause:

Flaking from a flaw due to shock

6.6.1

6.6.2

6.6.3



Part:
Outer ring of a double-row cylindrical roller bearing used for outer ring rolling (outer ring rotation)

Observation:
Cracks occur on outside surface

Cause:
Flat wear and heat generation due to non-rotation of the outer ring

6.6.4



Part:
Raceway surface of outer ring in Photo 6.6.4

Observation:
Outside surface crack developing on the raceway

6.6.5



Part:
Inner ring of a spherical roller bearing

Observation:
Axial cracks occur on raceway surface

Cause:
Large fitting stress due to temperature difference between shaft and inner ring

6.6.6



Part:
Cross section of a fractured inner ring in Photo 6.6.6

Observation:
Origin is directly beneath the raceway surface

6.6.7



Part:
Roller of a spherical roller bearing

Observation:
Axial cracks occur on rolling surface

6.6.8

6.7 CAGE DAMAGE

DAMAGE CONDITION

Cage damage includes cage deformation, fracture and wear. Fracture of cage pillar. Deformation of side face. Wear of pocket surface. Wear of guide surface.

POSSIBLE CAUSE

- › Poor mounting (bearing misalignment)
- › Poor handling
- › Large moment load
- › Shock and large vibration
- › Excessive rotation speed, sudden acceleration and deceleration
- › Poor lubrication
- › Temperature rise

COUNTERMEASURE

- › Check the mounting method
- › Check the temperature, rotation, and load conditions
- › Reduce the vibration
- › Select a different cage type
- › Select a different lubrication method and lubricant



Part:
Cage of a deep groove ball bearing

Observation:
Fracture of pressed-steel cage-pocket



Part:
Cage of an angular contact ball bearing

Observation:
Pocket pillar fractures from a cast iron machined cage

Cause:
Abnormal load action on cage due to misaligned mounting between inner and outer rings



Part:
Cage of an angular contact ball bearing

Observation:
Fracture of machined high-tension brass cage

6.7.1

6.7.2

6.7.3



Part:
Cage of a tapered roller bearing

Observation:
Pillar fractures of pressed-steel cage

6.7.4



Part:
Cage of an angular contact ball bearing

Observation:
Pressed-steel cage deformation

Cause:
Shock load due to poor handling

6.7.5



Part:
Cage of a cylindrical roller bearing

Observation:
Deformation of the side face of a machined high-tension brass cage

Cause:
Large shock during mounting

6.7.6



Part:
Cage of a cylindrical roller bearing

Observation:
Deformation and wear of a machined high-tension brass cage

6.7.7



Part:
Cage of an angular contact ball bearing

Observation:
Stepped wear on the outside surface and pocket surface of a machined high-tension brass cage

6.7.8

6.8 DENTING

DAMAGE CONDITION

When debris such as small metallic particles are caught in the rolling contact zone, denting occurs on the raceway surface or rolling element surface. Denting can occur at the rolling element pitch interval if there is a shock during the mounting (brinell dents).

POSSIBLE CAUSE

- › Debris such as metallic particles is caught between surfaces with relative motion
- › Excessive load
- › Shock during transport or mounting

COUNTERMEASURE

- › Wash the housing
- › Improve the sealing mechanism
- › Filter the lubrication oil
- › Improve the mounting and handling methods



Part:
Outer ring of a double-row tapered roller bearing

Observation:
Indentations on raceway surface

Cause:
Debris caught between rolling element and raceway



Part:
Inner ring of a tapered roller bearing

Observation:
Small and large indentations occur over entire raceway surface

Cause:
Debris caught between rolling element and raceway



Part:
Tapered rollers of Photo 6.8.2

Observation:
Small and large indentations occur over the rolling surface

Cause:
Debris caught between rolling element and raceway

6.8.1

6.8.2

6.8.3

DAMAGE CONDITION

The pitted surface has a dull luster which appears on the rolling element surface or raceway surface.

POSSIBLE CAUSE

- › Debris becomes caught in the lubricant
- › Exposure to moisture in the atmosphere
- › Poor lubrication

COUNTERMEASURE

- › Improve the sealing mechanism
- › Filter the lubrication oil thoroughly
- › Use a proper lubricant



Part:
Outer ring of a slewing bearing

Observation:
Pitting occurs on the raceway surface

Cause:
Rust at bottoms of indentations



Part:
Ball of Photo 6.9.1

Observation:
Pitting occurs on the rolling element surface

6.9.1

6.9.2

6.10 WEAR

DAMAGE CONDITION

Wear is surface deterioration due to sliding friction at the surface of the raceway, rolling elements, roller end faces, rib face, and cage pockets.

POSSIBLE CAUSE

- › Entry of debris
- › Progression from rust and electrical erosion
- › Poor lubrication
- › Sliding due to irregular motion of rolling elements

COUNTERMEASURE

- › Improve the sealing mechanism
- › Clean the housing
- › Filter the lubrication oil thoroughly
- › Check the lubricant and lubrication method
- › Prevent misalignment

**Part:**

Outer ring of a spherical roller bearing

Observation:

Wear having a wavy or concave-and-convex texture on loaded side of raceway surface

Cause:

Entry of debris under repeated vibration while stationary

**Part:**

Inner ring of a double-row tapered roller bearing

Observation:

Fretting wear of raceway and stepped wear on the rib face

Cause:

Fretting progression due to excessive load while stationary

**Part:**

Tapered rollers of Photo 6.10.2

Observation:

Stepped wear on the roller head and face

Cause:

Fretting progression due to excessive load while stationary

6.10.1

6.10.2

6.10.3

DAMAGE CONDITION

Wear occurs due to repeated sliding between the two surfaces. Fretting occurs at fitting surface and also at contact area between raceway ring and rolling elements. Fretting corrosion is another term used to describe the reddish brown or black worn particles.

POSSIBLE CAUSE

- › Poor lubrication
- › Vibration with a small amplitude
- › Insufficient interference

COUNTERMEASURE

- › Use a proper lubricant
- › Apply a preload
- › Check the interference fit
- › Apply a film of lubricant to the fitting surface



Part:
Inner ring of a deep groove ball bearing

Observation:
Fretting occurs on the bore surface


Cause:
Vibration



Part:
Inner ring of an angular contact ball bearing

Observation:
Notable fretting occurs over entire circumference of bore surface

Cause:
Insufficient interference fit



Part:
Outer ring of a double-row cylindrical roller bearing

Observation:
Fretting occurs on the raceway surface at roller pitch intervals

6.11.1

6.11.2

6.11.3

6.12 FALSE BRINELLING

DAMAGE CONDITION

Among the different types of fretting, false brinelling is the occurrence of hollow spots that resemble brinell dents, and are due to wear caused by vibration and swaying at the contact points between the rolling elements and raceway.

POSSIBLE CAUSE

- › Oscillation and vibration of a stationary bearing during such times as transporting
- › Oscillating motion with a small amplitude
- › Poor lubrications

COUNTERMEASURE

- › Secure the shaft and housing during transporting
- › Transport with the inner and outer rings packed separately
- › Reduce the vibration by preloading
- › Use a proper lubricant



Part:
Inner ring of a deep groove ball bearing

Observation:
False brinelling occurs on the raceway

Cause:
Vibration from an external source while stationary



Part:
Outer ring of Photo 6.12.1

Observation:
False brinelling occurs on the raceway

Cause:
Vibration from an external source while stationary



Part:
Rollers of a cylindrical roller bearing

Observation:
False brinelling occurs on rolling surface

Cause:
Vibration from an external source while stationary

6.12.1

6.12.2

6.12.3

DAMAGE CONDITION

Creep is the phenomenon in bearings where relative slipping occurs at the fitting surfaces and thereby creates a clearance at the fitting surface. Creep causes a shiny appearance, occasionally with scoring or wear.

POSSIBLE CAUSE

- › Insufficient interference or loose fit
- › Insufficient sleeve tightening

COUNTERMEASURE

- › Check the interference, and prevent rotation
- › Correct the sleeve tightening
- › Study the shaft and housing precision
- › Preload in the axial direction
- › Tighten the raceway ring side face
- › Apply adhesive to the fitting surface
- › Apply a film of lubricant to the fitting surface



Part:
Inner ring of a spherical roller bearing

Observation:
Creep accompanied by scoring of bore surface

Cause:
Insufficient interference



Part:
Outer ring of a spherical roller bearing

Observation:
Creep occurs over entire circumference of outside surface

Cause:
Loose fit between outer ring and housing

6.13.1

6.13.2

6.14 SEIZURE

DAMAGE CONDITION

When sudden overheating occurs during rotation, the bearing becomes discolored. Next, raceway rings, rolling elements, and cage will soften, melt and deform as damage accumulates.

POSSIBLE CAUSE

- › Poor lubrication
- › Excessive load (excessive preload)
- › Excessive rotational speed
- › Excessively small internal clearance
- › Entry of water and debris
- › Poor precision of shaft and housing, excessive shaft bending

COUNTERMEASURE

- › Study the lubricant and lubrication method
- › Reinvestigate the suitability of the bearing type selected
- › Study the preload, bearing clearance, and fitting
- › Improve the sealing mechanism
- › Check the precision of the shaft and housing
- › Improve the mounting method



Part:
Inner ring of a spherical roller bearing

Observation:
Raceway is discolored and melted. Worn particles from the cage were rolled and attached to the raceway

Cause:
Insufficient lubrication



Part:
Convex rollers of Photo 6.14.1

Observation:
Discoloration and melting of roller rolling surface, adhesion of worn particles from cage

Cause:
Insufficient lubrication

6.14.1

6.14.2



Part:
Inner ring of an angular contact ball bearing

Observation:
Raceway discoloration, melting occurs at ball pitch intervals

Cause:
Excessive preload



Part:
Outer ring in Photo 6.14.3

Observation:
Raceway discoloration, melting occurs at ball pitch intervals

Cause:
Excessive preload

6.14.3

6.14.4



Part:
Balls and cage of Photo 6.14.3

Observation:
Cage is damaged by melting, balls become discolored and melted

Cause:
Excessive preload

6.14.5

6.15 ELECTRICAL EROSION

DAMAGE CONDITION

When electric current passes through a bearing, arcing and burning occur through the thin oil film at points of contact between the race and rolling elements. The points of contact are melted locally to form “fluting” or groove-like corrugations which are seen by the naked eye. The magnification of these grooves will reveal crater-like depressions which indicate melting by arcing.

POSSIBLE CAUSE

- › Electrical potential difference between inner and outer rings
- › Electrical potential difference of a high frequency that is generated by instruments or substrates when used near a bearing

COUNTERMEASURE

- › Design electric circuits which prevent current flow through the bearings
- › Insulation of the bearing



Part:
Inner ring of a tapered roller bearing

Observation:
Striped pattern of erosion occurs on the raceway surface



Part:
Tapered rollers in Photo 6.15.1

Observation:
Striped pattern of erosion occurs on the rolling surface

6.15.1

6.15.2



Part:
Inner ring of a cylindrical roller bearing

Observation:
Belt pattern of electrical erosion
accompanied by pits on the raceway
surface



Part:
Balls of a groove ball bearing

Observation:
Electrical erosion has a dark color that
covers the entire ball surface



Part:
Inner ring of a deep groove ball bearing

Observation:
Fluting occurs on the raceway surface
(high frequency)



Part:
Outer ring of a deep groove ball bearing

Observation:
Fluting occurs on the raceway surface
(high frequency)

6.15.3

6.15.4

6.15.5

6.15.6

6.16 RUST AND CORROSION

DAMAGE CONDITION

Bearing rust and corrosion are pits on the surface of rings and rolling elements and may occur at the rolling element pitch on the rings or over the entire bearing surfaces.

POSSIBLE CAUSE

- › Entry of corrosive gas or water
- › Improper lubricant
- › Formation of water droplets due to condensation of moisture
- › High temperature and high humidity while stationary
- › Poor rust preventive treatment during transporting
- › Improper storage conditions
- › Improper handling

COUNTERMEASURE

- › Improve the sealing mechanism
- › Study the lubrication method
- › Anti-rust treatment for periods of non-running
- › Improve the storage methods
- › Improve the handling method

**Part:**

Outer ring of a cylindrical roller bearing

Observation:

Rust on the rib face and raceway surface

Cause:

Poor lubrication due to water entry

**Part:**

Inner ring of a spherical roller bearing

Observation:

Rust on raceway surface at roller pitch

Cause:

Entry of water into lubricant

**Part:**

Rollers of a spherical roller bearing

Observation:

Pit-shaped rust on rolling contact surface; corroded portions

Cause:

Moisture condensation during storage

6.16.1

6.16.2

6.16.3

6.17 MOUNTING FLAWS

NSK

DAMAGE CONDITION

Straight line scratches on surface of raceways or rolling elements caused during mounting or dismounting of bearing.

POSSIBLE CAUSE

- › Inclination of inner and outer rings during mounting or dismounting
- › Shock load during mounting or dismounting

COUNTERMEASURE

- › Use appropriate jig and tool
- › Avoid a shock load by use of a press machine
- › Center the relative mating parts during mounting



Part:
Inner ring of a cylindrical roller bearing

Observation:
Axial scratches on raceway surface

Cause:
Inclination of inner and outer rings during mounting



Part:
Outer ring of a double-row cylindrical roller bearing

Observation:
Axial scratches at roller pitch intervals on raceway surface

Cause:
Inclination of inner and outer rings during mounting



Part:
Rollers of a cylindrical roller bearing

Observation:
Axial scratches on rolling surface

Cause:
Inclination of inner and outer rings during mounting

6.17.1

6.17.2

6.17.3

6.18 DISCOLORATION

DAMAGE CONDITION

Discoloration of cage, rolling elements, and raceway ring occurs due to a reaction with lubricant and high temperature.

POSSIBLE CAUSE

- › Poor lubrication
- › Oil stain due to a reaction with lubricant
- › High temperature

COUNTERMEASURE

- › Improve the lubrication method

**Part:**

Inner ring of an angular contact ball bearing

Observation:

Bluish or purplish discoloration on raceway surface

Cause:

Heat generation due to poor lubrication

**Part:**

Inner ring of a 4-point contact bearing

Observation:

Bluish or purplish discoloration on raceway surface

Cause:

Heat generation due to poor lubrication

6.18.1

6.18.2

APPENDIX: BEARING DIAGNOSTIC CHART

NSK

DAMAGE NAME	LOCATION (PHENOMENON)	CAUSE										REMARKS	
		Stock • Shipping	Mounting	Shaft Housing	Sealed device Water • Debris	Temperature	Lubricant	Lubrication method	Excessive load Impact load	Moment	Ultra small load	High speed, High acceleration & deceleration	
1. Flaking (or Spalling)	Raceway, Rolling surface	●	●	●		●	●	●	●	●			●
2. Scoring	Raceway, Rolling surface	●	●	●		●	●	●	●	●		●	
	Bearing outside surface (Rolling contact)	●		●		●	●						
3. Peeling	Roller end face surface, Rib surface			●		●	●				●	●	
	Cage guide surface, Pocket surface		●*	●		●	●						* Mating rolling part
4. Fracture	Raceway, Rolling surface	●	●	●					●	●			
5. Smearing	Raceway collar, Rollers			●		●	●				●	●	
6. Cracks	Raceway rings, Rolling elements	●	●		●				●	●			
	Rib surface, Roller end face, Cage guide surface (Thermal crack)		●				●	●	●				
7. Cage damage	Deformation, Fracture	●	●						●	●			
	Wear	●		●		●	●	●	●	●		●	
8. Denting	Raceway, Rolling surface, (Innumerable small dents)			●			●						
	Raceway (Dents on the rolling element pitch)	●	●						●			●	
9. Pitting	Raceway, Rolling surface			●		●	●						
10. Wear	Raceway, Rolling surface, Rib surface, Roller end face	●		●		●	●						
11. Fretting	Raceway, Rolling surface	●	●	●		●	●	●			●	●	
	Bearing outside & bore, side surface (Contact with housing and shaft)		●	●					●				
12. False brinelling	Raceway, Rolling surface	●					●	●				●	
13. Creep	Fitting surface	●	●		●	●*	●*	●*	●		●		* Clearance fit
14. Seizure	Raceway ring, Rolling element, Cage	●	●	●		●	●	●	●	●	●	●	
15. Electrical erosion	Raceway, Rolling surface	●*	●*										* Electricity passing through the rolling element
16. Rust and corrosion	Raceway ring, Rolling element, Cage	●	●		●	●	●	●	●				
17. Mounting flaws	Raceway, Rolling surface	●	●				●	●	●				
18. Discoloration	Raceway ring, Rolling element, Cage					●	●	●					



NSK AMERICAS

United States
NSK Corporation
Ann Arbor MI
1.888.446.5675

Canada
NSK Canada Inc.
Mississauga ON
1.888.603.7667

Mexico
NSK Rodamientos Mexicana,
S.A. de C.V.
Silao Guanajuato MX
52.472.500.9500

Brazil
NSK Brasil Ltda.
Sao Paulo SP
55.11.3269.4700

Argentina
NSK Argentina SRL
Buenos Aires
54.11.4762.6556

Latin America
NSK Latin America Inc.
Miramar FL
1.305.477.0605

Website:
www.nskamericas.com
NSK Global: www.nsk.com

Every care has been taken to ensure the accuracy of the data contained in this brochure, but no liability can be accepted for any loss or damage suffered through errors or omissions.

Printed in the USA ©NSK 2024.
The contents of the publication are the copyright of the publishers.